









INSTALLATION MANUAL



A	B	C	D
			
E	F	G	H
			

INTEL LGA115X/1200/1700/18XX/1366/1356



AMD FM2/FM3/AM3/AM4/AM5

